

FASTSETTM STUCCO PATCH

PRODUCT No. 1139-76

PRODUCT DESCRIPTION

QUIKRETE® FastSet™ Stucco Patch is a fast setting, portland cement-based stucco patching material formulated to provide water repellency, minimal shrinkage, and improved durability.

PRODUCT USE

QUIKRETE® FastSet™ Stucco Patch can be used for full depth stucco repairs. QUIKRETE® FastSet™ Stucco Patch is manufactured as a complete product requiring only the addition of water. QUIKRETE® FastSet™ Stucco Patch can be painted after 2 hours.

SIZES

• 20 lb (9 kg) pails

YIELD

 Each 20 lb (9 kg) pail of QUIKRETE® FastSet™ Stucco Patch will yield approximately 0.2 ft³ (5.6 L) of patching plaster. Each 20 lb (9 kg) pail will repair approximately 10 ft² (0.93 m²) at a 1/4 in (6.3 mm) thickness.

TECHNICAL DATA

PHYSICAL/CHEMICAL PROPERTIES

QUIKRETE[®] FastSet[™] Stucco Patch achieves final set in 30 to 60 minutes after mixing and can be painted after 2 hours with a water-based latex paint. Only water-based coatings are recommended. Elastomeric coatings are preferred.

INSTALLATION

SURFACE PREPARATION

Proper surface preparation is essential to the successful application of QUIKRETE® FastSetTM Stucco Patch. All surfaces must be clean, structurally sound, and free of any loose or foreign materials. Hairline cracks should be widened with a chisel prior to application. Avoid V-shaped cracks. Dampen the surface thoroughly prior to application.

MIXING

QUIKRETE® FastSet™ Stucco Patch can be hand or machine mixed using a paddle style mortar mixer. Mix only as much material as can be applied in 15 to 25 minutes. Use approximately 3.5 pints (1.7 L) of potable water per 20 lb (9 kg) pail. Place the water in the mixing container then slowly add the QUIKRETE® FastSet™ Stucco Patch. Mix for 2 to 3 minutes, or until a trowelable consistency is achieved. Add additional amounts of water if necessary, to achieve the trowelable consistency. Excessive addition of water will delay setting, reduce strength, and delay the ability to paint. Do not add any additional materials such as portland cement, lime, sand, or admixture(s).

APPLICATION

Variation in water addition will affect color uniformity. Do not add additional water during application. QUIKRETE® FastSet™ Stucco Patch

DIVISION 9

09 24 00 Portland Cement Plastering



should be trowel applied to the damp surface. Apply a thin layer with heavy trowel pressure, and then go back and build up to the desired thickness

CURING

Keep moist to minimize cracking. Typical moist curing requires a fine mist of water three hours after application and a secondary misting after three additional hours. Mist applications should be increased for hot, dry, sunny, or windy conditions. Care must be exercised to avoid erosion damage to plaster surfaces when misting. The repair area should not be dampened prior to painting. If the repair is to be painted, moist curing is impractical.

PRECAUTIONS

- Do not apply when temperatures are expected to fall below 40 °F (4 °C) within a 24 hour period.
- Do not apply when temperatures are above 100 °F (38 °C).
- Do not apply when rain is expected within 2 hours after application.
- Mix only as much material as can be applied in 15 to 25 minutes.
- Do not exceed a maximum of 8 ft² (0.74 m²) in a single patch.
- The final color of QUIKRETE[®] FastSet[™] Stucco Patch, like other cementitious materials, may vary due to water addition, application techniques, and environmental conditions.

SAFETY

IMPORTANT: Read Safety Data Sheet carefully before using. WEAR IMPERVIOUS GLOVES, such as nitrile, mask, and eye protection.

DANGER: Causes severe skin burns and serious eye damage. Prolonged or repeated inhalation of dust may cause lung damage or cancer.

Keep out of reach of children

WARRANTY

NOTICE: Obtain the applicable LIMITED WARRANTY at www.quikrete.com/product-warranty or send a written request to The Quikrete Companies, LLC, Five Concourse Parkway, Atlanta, GA 30328, USA. Manufactured by or under the authority of The Quikrete Companies, LLC. © 2022 Quikrete International, Inc.